


Colonna guida estraibile (ISO 9182-5/DIN 9825) - R2021.46
Demountable guide pillar (ISO 9182-5/DIN 9825) - R2021.46



Note: Clamps and screws have to be ordered separately

42